

NOTES:-

- 1. The contractor should take all necessary measurements on site.
- 2. All dimensions shown on this drawing are approximate and for structural calculation purposes only.
- 3. Dimensions on this drawing should not be used for fabrication purposes.
- 4. Do not scale this drawing.
- 5. This drawing should be read in conjunction with the calculations.

IMPORTANT NOTE

The existing slab and ground have not been investigated by CLP structures, the pressures exerted on the ground and slab are shown on this drawing, however it is up to the client to satisfy himself that the existing ground and slab are adequate to support these loads.

Rev	Description	Ву	Date	Chk'd
	Purpose of Issue	Rev	Date	Auth



EMAIL: mail@CLP-Structures.co.uk TEL: 0117 3706357

Client

Elite Precast Concrete Ltd.

Project

Flood Wall

Wall Design Parameters and Limitations

Rev - Checked As noted Date April 16 Drawing Number 464-CL02 Α3